

Original User Manual

Series Touch Industrial PC



Christ Electronic Systems GmbH

Alpenstraße 34

87700 Memmingen

04/2023

www.christ-es.com

Instruction Manual: Touch Industrial PC

1	Identification	4
2	Product description	7
2.1	System Overview	8
2.2	Housing Variant VESA	9
2.3	Housing Variant VESA Automation	12
2.4	Housing variant Front Panel	20
2.5	Housing Variant Open Frame	22
3	Description Hardware	26
3.1	External Interfaces	26
3.2	Add-On	32
3.2.1	UPS (Uninterruptible Power Supply)	32
3.2.2	Add On Interface Main Device	32
3.2.3	Add On Interface Side	33
4	Assembly and Commissioning	34
4.1	Torque	34
4.2	Connection of the power supply	35
4.3	Earth Connection	35
4.4	Mounting VESA and VESA Automation	36
4.5	Mounting Front Panel	39
4.6	Mounting Open Frame	40
5	Commissioning	41
5.1	Unusual situations	41
5.1.1	Undefined state during start-up process	41
5.1.2	Sluggish touch behavior	41
6	Accessories and Spare Parts	43
6.1	Power supply	43
6.2	Stand	43
7	Software	44
7.1	BIOS Basic Settings	44
7.1.1	Set display resolution	45
7.1.2	COM Port configuration	45
7.1.3	Set Boot Priority	46
7.2	BIOS Update	48

Instruction Manual: Touch Industrial PC

7.2.1	Preparation	48
7.2.2	Perform Update	48
7.3	OBS Client	50
7.3.1	Activating the OBS Client	50
7.3.2	Functions of the OBS Client	50
7.4	Redo Backup and Recovery	51
7.5	Enhanced Write Filter EWF	51
8	Maintenance	52
8.1	Cleaning	52
8.2	Maintenance	52
9	Technical Data	53
9.1	Mechanical Specifications	53
9.2	Electrical Specifications	53
9.3	Power Consumption	54
9.4	Electromagnetic Compatibility	54
9.5	Environmental Conditions	55
9.6	Temperature test	55
9.7	IP Protection Class	55
9.8	Display Specifications	56
10	Standards and Approvals	58
10.1	CE Marking	58
10.2	RoHS	58
10.3	Electromagnetic Compatibility	58
10.4	Environmentally Appropriate Disposal	58
11	Technical Support	59
11.1	Device Seal	59

Instruction Manual: Touch Industrial PC

1 Identification

Target group

This document is not intended for end customers! Necessary safety instructions for the end customer must be passed on by the machine builder or system provider and adopted in the respective national language.

Intended use

The devices described in this documentation are intended to enable the user to control, operate, observe, drive and visualise certain processes.

Technical changes

Christ Electronic Systems GmbH reserves the right to change the information, designs and technical data contained in this documentation without prior notice.

History

The following editions of the manual have already been published:

Version	Comment
05/2021	First edition
04/2022	Avoid burn-in on displays UPS buffer duration Improvement: VESA 100 instead of VESA 75 with VESA Automation IP65 Integration of size 15" and 24" Dimensions updated
02/2023	Revision Identification Revision of the design of safety instructions Power Consumption updated Weight specifications updated Current capacity VESA Automation Electrical specifications updated Components VESA Automation updated Integration of size 10.4" Integration of housing variant Open Frame

Instruction Manual: Touch Industrial PC


04/2023	<p>Chapter 2.3 Housing Variant VESA Automation: Revision of components Pushbuttons, Emergency Stop, RFID</p> <p>Chapter 3.1 External Interfaces: Notice signal and data cables included</p> <p>Chapter 3 Description Hardware, Chapter 7 Software, Chapter 9 Technical Data, Chapter 10 Standards and Approvals: Introductory sentence inserted</p> <p>Chapter 5.1 Unusual situations: 5.1.2 Sluggish touch behavior added</p> <p>Chapter 2.6 Add-On: Moved, new chapter number 3.2</p> <p>Chapter 4.1 Temperature test: Moved, new chapter number 9.6</p> <p>Chapter 4.2 IP Protection Class: Moved, new chapter number 9.7</p> <p>Chapter 9.5 Environmental Conditions: Ambient Temperature instead of Operating Temperature</p> <p>Chapter 9.6 Temperature test: Ambient Temperature instead of Operating Temperature</p>
---------	--

Table 1: History


Instruction Manual: Touch Industrial PC

Design of safety instructions

⚠ DANGER	
	<p>Indicates an imminent danger</p> <p>Failure to follow the instructions may result in death or serious injury.</p>

⚠ WARNING	
	<p>Indicates a dangerous situation</p> <p>Failure to follow the instructions may result in serious injury.</p>

⚠ CAUTION	
	<p>Indicates a possible dangerous situation</p> <p>Failure to follow the instruction may result in injury.</p>

NOTICE	
	<p>Indicates user tips and useful information</p> <p>Important information to avoid malfunctions.</p>

Instruction Manual: Touch Industrial PC

2 Product description

Every industry has its own requirements for machine and system operation. To meet all of them, there are different housing variants with industry-specific features.

All touch panels are equipped with multitouch technology in various inch sizes as standard. This means that gesture control, as used on tablets or smart phones, is no problem. This makes machine operation particularly user-friendly.

Christ also offers the greatest possible flexibility in terms of operating systems with Windows 10 or Linux distributions. The sophisticated device design enables use in large temperature ranges completely without fans. This enables versatile use without any maintenance effort.

Industrial PCs with their robust housing design are ideal for use in demanding industrial environments. Due to optimal touch configuration, smooth operation is possible even with gloves. Even with residues on the display such as moisture, dirt or oils, the touch panel can be operated without errors. The anodized front frame protects the panel from mechanical influences.

The extension of the protection class is particularly easy by using a rear cover extension. In this way, protection class IP65 is achieved. The Industrial PCs can be mounted on support arms as well as installed in housing cutouts.

The hygienic version of the touch panel has a stainless steel housing and is completely IP69 protected. It is particularly suitable for use in hygienically demanding environments such as the pharmaceutical or food industry. Glove operation is also possible here with the help of an adapted touch.

Another aspect is the scalability of performance. A distinction is made here between different configuration levels: monitor, distance monitor (for use over long distances), web panel and particularly powerful panel PCs with Intel® Celeron® or Core™ i3, i5, or i7 processors.

Instruction Manual: Touch Industrial PC

2.1 System Overview

Argon

CPU	Intel® Celeron™ N3350 1.1 GHz
Graphic	Intel® HD Graphics 500 200 Hz
Memory	1 x DDR3 Slot, max. 8 GB
BIOS	AMI Optio 5 BIOS
Interfaces	2 x USB 3.0 Port (Type A) 2 x 1 GBit Ethernet (RJ45) 1 x RS-232 / RS-422 / RS-485 (Bios setting) (RJ50) 1 x Display Port 1.0

Table 2: System overview Argon

Titanium

CPU	Intel® Celeron™ 3965U 2.2 GHz	Intel® Core™ i3-7100U 2.4 GHz	Intel® Core™ i5-7300U 2.6 GHz	Intel® Core™ i7-7600U 2.8 GHz
Graphic	Intel® HD Graphics 610	Intel® HD Graphics 620		
Memory	2 x DDR4 slot, in summary max. 32 GB			
BIOS	AMI Optio 5 BIOS			
Interfaces	4 x USB: 2 x USB 2.0 Port (Type A); 2 x USB 3.0 Port (Type A) 2 x 1 GBit Ethernet (RJ45) 1 x RS-232 / RS-422 / RS-485 (Bios setting) (Sub-D) 1 x Display Port 1.1			

Table 3: System overview Titanium

Instruction Manual: Touch Industrial PC

2.2 Housing Variant VESA




Illustration 1: VESA Front




Illustration 2: VESA Rear

1	VESA MIS-D, 100
2	VESA MIS-D, 75
3	Interface Area

Table 4: VESA Front and VESA Rear




Illustration 3: VESA IP65 Front




Illustration 4: VESA IP65 Rear

1	VESA MIS-D, 75
2	Interface Cover

Table 5: VESA IP65 Front and VESA IP65 Rear

Instruction Manual: Touch Industrial PC




Illustration 5: Dimensions VESA




Illustration 6: Dimensions VESA Rear

Dimensions are given in millimeters.

Instruction Manual: Touch Industrial PC

Size	A	B	C	D
7"	211	144	55	75
10.1"	276	190	58	105
10.4"	274	215	58	130
12.1"	325	222	58	137
13.3"	357	224	58	148
15"	369	288	58	149
15.6"	412	256	58	149
18.5"	477	293	61	149
21.5"	548	334	61	149
24"	604	367	61	149

Table 6: Dimensions VESA




Illustration 7: VESA IP65 Cover

The cover for IP65 protection is available for sizes 13.3 to 24.

Instruction Manual: Touch Industrial PC

2.3 Housing Variant VESA Automation




Illustration 8: VESA Automation Front




Illustration 9: VESA Automation Rear

1	VESA MIS-D, 100
2	VESA MIS-D, 75
3	Interface Area
4	Extension Connector

Table 7: VESA Automation Front and VESA Automation Rear

Instruction Manual: Touch Industrial PC




Illustration 10: VESA Automation IP65 Front




Illustration 11: VESA Automation IP65 Rear

1	VESA MIS-D, 100
2	Interface Cover

Table 8: VESA Automation IP65 Front and VESA Automation IP65 Rear





Illustration 12: Dimensions VESA Automation

Instruction Manual: Touch Industrial PC




Illustration 13: Dimensions VESA Automation Rear

Dimensions are given in millimeters.

Size	A	B	C	D
13.3"	357	288	62	189
15.6"	412	320	62	189
18.5"	477	357	62	189
21.5"	548	398	62	189
24"	604	431	62	189

Table 9: Dimensions VESA Automation




Illustration 14: VESA Automation IP65 Cover

The cover for IP65 protection is available for sizes 13.3 to 24.

Instruction Manual: Touch Industrial PC

Pushbuttons



Series	SHORTRON® base-plate mounting
Degree of protection	IP65
Travel	2.3 mm
Illumination	Yes, white LED
Labeling Option	Yes ¹
Front Bezel	Silver-Coloured
Operating Temperature	-25 °C ... 70 °C
Contact Elements	max. 2 x NC / 2 x NO / 1 x NC + 1 x NO
Nameplate	Transparent: Blue, Yellow, Green, Transparent, Red, White Non-transparent: Black

Key Lock Switch



Series	SHORTRON® base-plate mounting
Degree of protection	IP65
Switchin function	Latching
Illumination	No
Labeling Option	No
Front Bezel	Silver-Coloured
Operating Temperature	-25 °C ... 70 °C
Contact Elements	max. 2 x NC / 2 x NO / 1 x NC + 1 x NO

¹ Possible designation plates are provided by your contact person

Instruction Manual: Touch Industrial PC

Selector Switch



Series	SHORTRON® base-plate mounting
Degree of protection	IP65
Switching function	Latching / non latching
Illumination	Yes, white LED
Labeling Option	No
Front Bezel	Silver-Coloured
Operating temperature	-25 °C ... 70 °C
Contact Elements	max. 2 x NC / 2 x NO / 1 x NC + 1 x NO

Emergency Stop



Series	SHORTRON® base-plate mounting
Type	FRVKZ
Degree of protection	IP65
Travel	2.3 mm
Illumination	No
Labelling Option	No
Front Bezel	Yellow
Operating Temperature	-25°C ... 70°C
Contact Elements	2 x Ö + 1 x S
Switching Position Indicator	Yes
Release	Twist right or left
Anti-lock Collar	Yes

USB



Degree of protection	IP65
USB	USB 2.0
Illumination	No
Labelling Option	No
Front Bezel	Black
Operating Temperature	-25°C ... 80°C

Instruction Manual: Touch Industrial PC

RFID

Manufacturer	ELATEC GmbH
Type	TWN4 MULTITECH NANO M
Degree of protection	IP65
Frequencies	125 kHz / 13.56 MHz
Operating temperature	-25°C ... 80°C
Transponder	<p>125 KHz: AWID, Cardax¹, CASI-RUSCO, Deister¹, EM4100, 4102, 4200², EM4050, 4150, 4450, 4550, EM4305³, FDX-B⁴, EM4105⁴, UltraProx⁴, HITAG 1⁵, HITAG 2⁵, HITAG S⁵, ICT⁶, IDTECK, Isonas, Keri, Miro, Nedap¹, PAC⁶, Pyramid, Q5, T5557, T5567, T5577, TIRIS/HDX⁴, TITAN (EM4050), UNIQUE, ZODIAC</p> <p>13.56 MHz / ISO14443A: LEGIC Advant⁷, MIFARE Classic EV1⁸, MIFARE Classic, MIFARE Mini, MIFARE DESFire EV1, MIFARE DESFire EV2⁹, MIFARE DESFire Light⁶, MIFARE Plus S, X, MIFARE Pro X¹⁰, MIFARE Smart MX¹⁰, MIFARE Ultralight, MIFARE Ultralight C, MIFARE Ultralight EV1⁸, NTAG2xx, SLE44R35¹⁰, SLE66Rxx (my-d move)¹⁰, Topaz</p> <p>13.56 MHz / ISO18092 ECMA-340: NFC Forum Tag 1-5, NFC Peer-to-Peer, Sony FeliCa¹¹, NFC Active and passive communication mode</p> <p>13.56 MHz / ISO14443B: Calypso¹⁰, Calypso Innovatron protocol¹⁰, CEPAS¹⁰, HID iCLASS⁷, Moneo¹⁰, Pico Pass¹², SRI4K, SRIX4K, SRI512, SRT512</p> <p>13.56 MHz / ISO15693: EM4x33¹⁰, EM4x35¹⁰, HID iCLASS⁷, HID iCLASS SE/SR⁷, ICODE SLI, LEGIC Advant⁷, M24LR16/64, MB89R118/119, SRF55Vxx (my-d vicinity)¹⁰, Tag-it, PicoPass¹²</p>

¹ hash value only

² only emulation of 4100, 4102

³ from FW V4.05

⁴ 134.2 kHz only

⁵ without encryption

⁶ on request

⁷ UID only

⁸ read/write enhanced security features on request

⁹ EV2/EV3 supported as part of the EV1 downward compatibility

¹⁰ read/write in direct chip command mode

¹¹ UID + read/write public area

¹² UID only, read/write on request

Instruction Manual: Touch Industrial PC

Manufacturer	ELATEC GmbH
Type	TWN4 MULTITECH NANO LEGIC 42 M
Degree of protection	IP65
Frequencies	125 kHz / 13.56 MHz
Operating temperature	-25°C ... 80°C
Transponder	<p>125 KHz: AWID, Cardax¹, CASI-RUSCO, Deister¹, EM4100, EM4102, EM4200², EM4050, EM4150, EM4450, EM4550, EM4305, HITAG 1³, HITAG 2³, HITAG S³, ICT⁴, IDTECK, ISONAS, Keri, Miro, Nedap¹, Pyramid, Q5, T5557, T5567, T5577, TITAN (EM4050), UNIQUE, ZODIAC</p> <p>13.56 MHz / ISO14443A: LEGIC Advant, MIFARE Classic EV1⁵, MIFARE Classic, MIFARE Mini, MIFARE DESFire EV1, MIFARE DESFire EV2⁶, MIFARE DESFire EV3⁶, MIFARE DESFire Light⁴, MIFARE Plus S/X, MIFARE Smart MX⁷, MIFARE Ultralight, MIFARE Ultralight C, MIFARE Ultralight EV1⁵, NTAG2xx, SLE44R35⁷, SLE66Rxx (my-d move)⁷, HID iCLASS DESFire⁸, HID iCLASS MIFARE Classic⁸, HID iCLASS SEOS⁸</p> <p>13.56 MHz / ISO18092 ECMA-340: NFC Forum Tag 1-5⁹, Sony FeliCa¹⁰</p> <p>13.56 MHz / ISO14443B: Calypso⁷, CEPAS⁷, HID iCLASS⁸, Pico Pass⁸</p> <p>13.56 MHz / ISO15693: EM4x33⁷, EM4x35⁷, HID iCLASS⁸, HID iCLASS SE/SR/Elite⁸, ICODE SLI, LEGIC Advant, M24LR16/64, SRF55Vxx (my-d vicinity)⁷, Tag-it, PicoPass⁸</p> <p>LEGIC Prime: LEGIC Prime</p>

Profinet

The GSD file for project planning is provided by Christ. This describes the input/output image of the Christ device and must be embedded in the configuration software. The input/output image or the variables can then be used in the control programme.

The IP address is assigned to the IO device (Profinet module installed in the Christ device) by the PROFINET IO controller (PLC controller of the customer).

¹ hash value only

² only emulation of 4100, 4102

³ without encryption

⁴ on request

⁵ read/write enhanced security features on request

⁶ supported as part of the EV1 downward compatibility

⁷ read/write in direct chip command mode

⁸ UID only

⁹ NFC Forum Tag 1 not supported

¹⁰ UID + read/write public area

Instruction Manual: Touch Industrial PC

In the delivery state, the station name of the IO device is not set. This must be assigned by the IO controller according to the Profinet specification so that communication can take place.

For more information on Profinet, visit the homepage <https://www.profibus.com/>.

EtherCAT

The XML file for project planning is provided by Christ. This describes the input/output image of the Christ device and must be embedded in the configuration software. The input/output image or the variables can then be used in the control programme.

For more information on EtherCAT, visit the homepage <https://www.ethercat.org/>.

EtherNet/IP

By default, the Ethernet/IP address is assigned via DHCP. A DHCP server must be available in the network for this.

To be able to assign the IP address manually, there is, for example, the tool BootP that simulates a DHCP server.

Alternatively, there is the option of having Christ assign a fixed IP address.

The EDS file for project planning is provided by Christ. This describes the input/output image of the Christ device and must be embedded in the configuration software. The input/output image or the variables can then be used in the control programme.

For more information on EtherNet/IP, visit the homepage <https://www.odva.org/>.

Instruction Manual: Touch Industrial PC

2.4 Housing variant Front Panel




Illustration 15: Front Panel Front




Illustration 16: Front Panel Rear

1	Fastening Clamp
2	Interface Area
3	Seal

Table 10: Front Panel Front und Front Panel Rear





Illustration 17: Dimensions Front Panel

Instruction Manual: Touch Industrial PC




Illustration 18: Dimensions Front Panel Rear

The drawing of the Front Panel is exemplary and may show deviations to the device. The detailed technical drawing can be found in the specific data sheet.

Dimensions are given in millimeters.

Size	A	B	C	D
7"	208	145	47	7
10.1"	273	190	50	7
10.4"	274	217	50	7
12.1"	322	222	52	7
13.3"	354	224	50	7
15"	366	288	52	7
15.6"	409	256	52	7
18.5"	474	293	52	7
21.5"	545	334	52	7
24"	601	367	54	7

Table 11: Dimensions Front Panel




Illustration 19: Dimensions Front Panel Cutout

Instruction Manual: Touch Industrial PC

Dimensions are given in millimeters.

Size	E	F	G
7"	196	134	R 10
10.1"	262	179	R 10
10.4"	262	206	R 10
12.1"	310	211	R 10
13.3"	343	213	R 10
15"	355	277	R 10
15.6"	397	245	R 10
18.5"	463	283	R 10
21.5"	533	323	R 10
24"	590	356	R 10

Table 12: Dimensions Front Panel Cutout

2.5 Housing Variant Open Frame




Illustration 20: Open Frame Front




Illustration 21: Open Frame Rear

1	Fastening Clamp
2	Interface Area
3	Seal

Table 13: Open Frame Front und Open Frame Rear

Instruction Manual: Touch Industrial PC




Illustration 22: Dimensions Open Frame




Illustration 23: Dimensions Open Frame Rear

The drawing of the Open Frame is exemplary and may show deviations to the device. The detailed technical drawing can be found in the specific data sheet.

Dimensions are given in millimeters.

Instruction Manual: Touch Industrial PC

Size	A	B	C	D	E
7"	192.2 ± 0.2	131.2 ± 0.2	56	20	5.7
10.1"	257.6 ± 0.2	176.2 ± 0.2	59	20	5.7
10.4"	254.8 ± 0.2	202 ± 0.2	59	20	5.7
12.1"	305.9 ± 0.2	208 ± 0.2	59	20	5.7
13.3"	338.7 ± 0.2	210.3 ± 0.2	59	20	5.7
15"	350.3 ± 0.2	274.3 ± 0.2	59	20	5.7
15.6"	393 ± 0.3	242.4 ± 0.3	59	20	5.7
18.5"	458.6 ± 0.3	279.6 ± 0.3	59	20	5.7
21.5"	528.8 ± 0.3	320.3 ± 0.3	59	20	5.7
24"	585.5 ± 0.3	353 ± 0.3	63	24	5.7

Table 14: Dimensions Open Frame




Illustration 24: Dimensions Open Frame Cutout Counterplate




Illustration 25: Dimensions Open Frame Cutout Front- and Spacerplate

Dimensions are given in millimeters.

Size	F	G	H	K
7"	182	121	R 5	R10 ± 0.2
10.1"	248	166	R 5	R10 ± 0.2
10.4"	245	192	R 5	R10 ± 0.2
12.1"	296	198	R 5	R10 ± 0.2
13.3"	329	200	R 5	R10 ± 0.2
15"	340	264	R 5	R10 ± 0.2
15.6"	383	232	R 5	R10 ± 0.2
18.5"	449	270	R 5	R10 ± 0.2
21.5"	519	310	R 5	R10 ± 0.2
24"	575	343	R 5	R10 ± 0.2

Table 15: Dimensions Open Frame Cutout

Instruction Manual: Touch Industrial PC

Installation Open Frame

The actual cut-out-dimensions of the front- and spacerplate need to be subjected to the prevalent assembly situation (production tolerances, ambient temperature, etc.) and therefore to be defined by the customer.




Illustration 26: Installation Open Frame Cutout



1	Frontplate
2	Spacerplate
3	Counterplate

Instruction Manual: Touch Industrial PC

3 Description Hardware

The description of the hardware refers to the device interfaces and the possible extensions for the device.

3.1 External Interfaces

NOTICE	
	External cable for Power Supply, Signal or Periphery Malfunction occur ➤ Prepare a proper earth connection on the power supply
NOTICE	
	Signal and data cables Malfunction occur ➤ Signal and data cables must be shielded and of high quality.

Supply Connector screwable


	Mating Connector	Phoenix Connector MC 1,5 / 3-STF-3.5 (screwable)	
	PIN	Function	Description
	1	GND	Ground
	2	FE	Functional Earth
	3	+24 VDC	Supply

Table 16: Pinout Supply Connector screwable

USB Host 2.0 (Type A)



	PIN	Function	Description
	1	VBUS	USB VCC
	2	D-	USB Data-
	3	D+	USB Data+
	4	GND	USB Ground

Table 17: Pinout USB 2.0

Instruction Manual: Touch Industrial PC


USB Host 3.0 (Type A)



PIN	Function	Description
1	VBUS	USB VCC
2	D-	USB Data-
3	D+	USB Data+
4	GND	USB Ground
5	StdA_SSRX-	SuperSpeed transmitter differential pair
6	StdA_SSRX+	SuperSpeed transmitter differential pair
7	GND_DRAIN	Ground for signal return
8	StdA_SSTX-	SuperSpeed receiver differential pair
9	StdA_SSTX+	SuperSpeed receiver differential pair

Table 18: Pinout USB 3.0


Ethernet



PIN	Function	Description
1	D1+	Transmit Data +
2	D1-	Transmit Data -
3	D2+	Receive Data+
4	D3+	Bidirectional +
5	D3-	Bidirectional -
6	D2-	Receive Data -
7	D4+	Bidirectional +
8	D4-	Bidirectional -

Table 19: Pinout Ethernet

WLAN




Mating Connector	RP-SMA
Transmission Standard	802.11 ac/a/b/g/n (2.4 GHz, 5 GHz)

Table 20: Pinout WLAN

Instruction Manual: Touch Industrial PC

Serial Connector (Titanium)




	RS-232		RS-422		RS-485	
PIN	Function	Description	Function	Description	Function	Description
1	DCD	Data Carrier Detect	TX-	Transmitter Differential Pair -	DATA-	Data Differential Pair A
2	RX	Receive Data	TX+	Transmitter Differential Pair +	DATA+	Data Differential Pair B
3	TX	Transmit Data	RX+	Receiver Differential Pair +	--	--
4	DTR	Data Transmit Ready	RX-	Receiver Differential Pair -	--	--
5	GND	Ground	GND	Ground	GND	Ground
6	DSR	Data Set Ready	--	--	--	--
7	RTS	Ready To Send	--	--	--	--
8	CTS	Clear To Send	--	--	--	--
9	RI	Ring Indicator	--	--	--	--

Table 21: Pinout Serial Connector Titanium

Instruction Manual: Touch Industrial PC


Serial Connector (Celeron N3350 Argon)



	RS-232		RS-422		RS-485	
PIN	Function	Description	Function	Description	Function	Description
1	DSR	Data Set Ready	--	--	--	--
2	GND	Ground	GND	Ground	GND	Ground
3	GND	Ground	GND	Ground	GND	Ground
4	TXD	Transmit Data	RX+	Receiver Differential Pair +	--	--
5	RXD	Receive Data	TX+	Transmitter Differential Pair +	DATA+	Data Differential Pair B
6	DCD	Data Carrier Detect	TX-	Transmitter Differential Pair -	DATA-	Data Differential Pair A
7	DTR	Data Terminal Ready	RX-	Receiver Differential Pair -	--	--
8	CTS	Clear To Send	--	--	--	--
9	RTS	Request To Send	--	--	--	--
10	RI	Ring Indicator	--	--	--	--

Table 22: Pinout Serial Connector Celeron N3350 Argon

UPS




Mating Connector		MC 1,5/ 4-STF-3,5 (screwable)	
PIN	Function	Description	
1	GND	Ground	
2	GND	Ground	
3	Capacitor	Capacitor	
4	Capacitor State	Charge State Capacitor	

Table 23: Pinout UPS

Instruction Manual: Touch Industrial PC

Display Port



PIN	Function	Description
1	DP data 0+	DP data 0+
2	GND	Ground
3	DP data0-	DP data0-
4	DP data1 +	DP data1 +
5	GND	Ground
6	DP data1 -	DP data1 -
7	DP data2 +	DP data2 +
8	GND	Ground
9	DP data2-	DP data2-
10	DP data3 +	DP data3 +
11	GND	Ground
12	DP data3-	DP data3-
13	CONFIG1 CAD	Cable adapter recognized
14	CONFIG2	Ground (Pull-Down)
15	AUX_CH+	Additional device +
16	GND	Ground
17	AUX_CH-	Additional device -
18	HPD	Hot Plug recognized
19	GND	Ground
20	DP_PWR 3,3V	Power Supply DP

Table 24: Pinout Display Port



With the DP1.0 it is not possible to display an image on DVI / HDMI devices. An active adapter with properties of DP++ is required for this.¹




Display Port 1.1 is also known as "Dual-Mode Display Port" and "Display Port++". This allows compatibility with DVI and HDMI.

¹ The Argon board uses DP1.0

Instruction Manual: Touch Industrial PC

Phoenix DMCV 1,5/13-G1F-3,5-LR P20THR




PIN	Function	Description	PIN	Function	Description
A1	P1_C1	Position 1 Contact 1	B7	P4_C2	Position 4 Contact 2
B1	P1_C2	Position 1 Contact 2	A8	P4_C24	Position 4 Contact 24
A2	P1_C24	Position 1 Contact 24 VDC	B8	P4_LED	Position 4 LED
B2	P1_LED	Position 1 LED	A9	E_C1	Emergency Stop Contact 1
A3	P2_C1	Position 2 Contact 1	B9	E_C2	Emergency Stop Contact 2
B3	P2_C2	Position 2 Contact 2	A10	E_C3	Emergency Stop Contact 3
A4	P2_C24	Position 2 Contact 24 VDC	B10	E_C4	Emergency Stop Contact 4
B4	P2_LED	Position 2 LED	A11	E_C5	Emergency Stop Contact 5
A5	P3_C1	Position 3 Contact 1	B11	E_C6	Emergency Stop Contact 6
B5	P3_C2	Position 3 LED Contact 2	A12	GND	Ground
A6	P3_C24	Position 3 Contact 24 VDC	B12	24 VDC	+24 VDC
B6	P3_LED	Position 3 LED	A13	GND	Ground
A7	P4_C1	Position 4 Contact 1	B13	24 VDC	+24 VDC

Table 25: Pinning Phoenix DMCV 1,5/13-G1F-3,5-LR P20THR

The pin assignment may vary. This can be found in the device-specific data sheet.

Phoenix DMCV 1,5/8-G1F-3,5-LR P20THR



PIN	Function	Description	PIN	Function	Description
A1	P5_C1	Position 5 Contact 1	A5	P7_C1	Position 7 Contact 1
B1	P5_C2	Position 5 Contact 2	B5	P7_C2	Position 7 Contact 2
A2	P5_C24	Position 5 Contact 24 VDC	A6	P7_C24	Position 7 Contact 24 VDC
B2	P5_LED	Position 5 LED	B6	P7_LED	Position 7 LED
A3	P6_C1	Position 6 Contact 1	A7	P8_C1	Position 8 Contact 1

Instruction Manual: Touch Industrial PC

B3	P6_C2	Position 6 Contact 2	B7	P8_C2	Position 8 Contact 2
A4	P6_C24	Position 6 Contact 24 VDC	A8	P8_C24	Position 8 Contact 24 VDC
B4	P6_LED	Position 6 LED	B8	P8_LED	Position 8 Contact LED

Table 26: Pinning Phoenix DMCV 1,5/8-G1F-3,5-LR P20THR

The pin assignment may vary. This can be found in the device-specific data sheet.

3.2 Add-On

In the following all extension possibilities are shown.

3.2.1 UPS (Uninterruptible Power Supply)

Energy Storage	400 Ws / 650 Ws
Charge Duration	90 % in 45 seconds 100 % in 80 seconds
Configuration	Shutdown Time Dimming Time Dimming Intensity

Energy storage value: see technical data sheet.

The instruction for the UPS can be found in the download section of the Christ website: [Downloads](#)

The device was operated with the following conditions: operating system Windows 10 IoT, no applications, display brightness 0 %.

It must be ensured that the customer application is ended quickly enough for the panel to shut down properly. Otherwise no protection against data loss or any other disfunction can be guaranteed. Depending on the CPU utilization, display and peripherals, the buffer time can be significantly shorter.

The exact buffer duration must be determined anew in every system setup.

Intel® Celeron™ 3965U	59 s
Intel® Core™ i3-7100U	57 s
Intel® Core™ i5-7300U	34 s
Intel® Core™ i7-7600U	38 s
Intel® Celeron™ N3350	99 s

Table 27: UPS buffer duration

3.2.2 Add On Interface Main Device

Instruction Manual: Touch Industrial PC



Ethernet (1 x 100 Mbit + 2 x USB 2.0)

Interface Ethernet	1 x RJ45
Data Rate	100 Mbit
Interface USB	2 x USB Host 2.0 (Type A)
Max. Workload	0,5 A for both USB interfaces


Table 28: Add On Ethernet and USB

WLAN Connector

WLAN Standards	802.11 ac/a/b/g/n (2.4 GHz, 5 GHz)
Interface	SMA

Table 29: Wireless LAN

3.2.3 Add On Interface Side



USB 2.0 side

Interface	1 x USB Host 2.0 (Type A)
Degree of protection	IP64 (IP67 with protection cap)

Table 30: Add On side USB 2.0

USB 3.0 side (only Titanium Board)

Interface	1 x USB Host 3.0 (Type A)
Degree of protection	IP64 (IP67 with protection cap)

Table 31: Add On side USB 3.0

The USB 3.0 interface side is only supported by devices with Titanium Board.

Power Button side



Type	1 x MCS 16 (Manufacturer: Schurter)
Degree of protection	IP65

Table 32: Add On side Power Button

Instruction Manual: Touch Industrial PC

4 Assembly and Commissioning

This chapter describes all the steps for assembly. The following warnings are safety instructions that must be applied throughout the assembly chapter and in every other life cycle of the device.

⚠ DANGER	
	Danger from electric shock, explosion or electric arc Serious injury or death ➤ Pull out the mains plug and do not open the covers
⚠ WARNING	
	Dropping a device Injuries and bruises to the legs and / or feet ➤ Wear safety shoes

Note for the installation site

This device is not designed for outdoor use.

Make sure that the ambient temperature and humidity are within the ranges which are specified under [Environmental Conditions](#).

Do not install the device directly in the sunlight.

Make sure that the device is installed so that is accessible for the operator.

Installation instructions

Check the package contents for any visible damage and for completeness.

In case of damage, do not install the device and contact the [Christ Service](#).

Preparing the Cut-Out

The strength of the material of the mounting cutout must be sufficiently high.

The dimensions for the mounting cutouts are listed in the chapters [Housing variant front panel](#) and [Open Frame](#).

4.1 Torque

All screws must be tightened with a minimum torque.

Screw	Torque
M3	1 Nm
M4	2,3 Nm

Instruction Manual: Touch Industrial PC

4.2 Connection of the power supply

Use conductors with a cross-section of 0.75 mm² to 1.5 mm². Use the MC 1,5/ 3-STF-3,5 BKBDWH:GND Q PCB connector from Phoenix.

Strip the insulation from the individual wires of the conductor (1). Insert these into the connection contacts (3) of the PCB connector and tighten the screw contacts (2) with a screwdriver and a maximum torque of 0.3 Nm.

The rear view (4) of the connector is shown for clarification.





Illustration 27: Connection of the power supply


4.3 Earth Connection

NOTICE	
	Earthing not connected
	Not guaranteed functionality of the device ➤ All earth connections must be connected to an earth point

At the earthing connection, a line must be laid to the central earthing point of the control cabinet or the system. The earthing connection is marked with a label.



Earth connection



Label

Instruction Manual: Touch Industrial PC

4.4 Mounting VESA and VESA Automation

VESA

The VESA housing variant is executed in two different VESA sizes.

- VESA MIS-D, 75
- VESA MIS-D, 100

There are four mounting threads with the measurement of M4 x 5. The fixing screws are not included in the delivery attachment of the device because of the different installation situation.

In the assembly drawing, any support arm was used as an example.

Step 1:

Dock the unit onto the support arm and screw it on

Final situation:

Device is mounted to the support arm




Illustration 28: Mounting VESA Step 1




Illustration 29: Mounting VESA final situation

Instruction Manual: Touch Industrial PC

VESA IP65

For the housing variant VESA which has included the IP65 cover, the device can only be mounted with the VESA MIS-D, 75 if the cables are routed through the cutout.

There are four mounting threads with the measurement of M4 x 5. The fixing screws are not included in the delivery attachment of the device because of the different installation situation.

Initial situation

Mounting arm and device are not connected

Step 1:

Loosen the screws of the IP cover and remove it




Illustration 30: Mounting VESA IP65 initial situation




Illustration 31: Mounting VESA IP65 Step 1

Step 2:

Fix the IP cover with the two lower screws to the mounting arm

Step 3:

Hanging in the device into the IP cover, connecting the cables and straighten up the device




Illustration 32: Mounting VESA IP65 Step 2




Illustration 33: Mounting VESA IP65 Step 3

Instruction Manual: Touch Industrial PC

Step 4:

Hold up the device and tighten the screws




Illustration 34: Mounting VESA IP65 Step 4

Final situation:

Device is mounted to the mounting arm





Illustration 35: Mounting VESA IP65 final situation

Instruction Manual: Touch Industrial PC

4.5 Mounting Front Panel

NOTICE	
	<p>Seal does not close</p> <p>Moisture penetration into the device</p> <p>➤ Tighten the screws with a defined torque</p>

Step 1:

Install the front panel into the cutout




Illustration 36: Mounting Front Panel Step 1

Step 2:

The fastening clamps must lie entirely behind the mounting plate




Illustration 37: Mounting Front Panel Step 2

Step 3:

Turn the fastening clamps outwards and tighten them with a torque of at least 1Nm




Illustration 38: Mounting Front Panel Step 3

Instruction Manual: Touch Industrial PC

4.6 Mounting Open Frame

Step 1:

Install the Open Frame Panel into the cutout




Illustration 39: Mounting Open Frame Step 1

Step 2:

- 1 - Lightly screw the grub screw into the mounting bracket
- 2 - Insert the mounting bracket into the slots
- 3 - Engage the mounting bracket to one side




Illustration 40: Mounting Open Frame Step 2

Schritt 3:

Tighten grub screw with a torque of min. 1 Nm




Illustration 41: Mounting Open Frame Step 3

Instruction Manual: Touch Industrial PC

5 Commissioning

To put the device into operation, connect the power supply to the unit.

The device starts.

Further steps for commissioning are not necessary.

5.1 Unusual situations

Under certain circumstances, the unit may behave in an unusual way. These are listed below.

5.1.1 Undefined state during start-up process

Description of error:

The device does not start completely, does not display anything.

Description:

There are two reasons why the errors may occur. These can both occur together or separately. The CPU board needs a stable power supply above 9.6 VDC in the first milliseconds of the start-up process. If the voltage rises too slowly during start-up, or falls again below 4.5 VDC, an undefined condition occurs. The delay is generated by an electronic fuse, for example. The voltage drop can occur when several components in the same circuit are started simultaneously.

Affected CPU boards:

- Argon: Intel® Celeron™ N3350 1.1 GHz

Solution:

If the device does not have a UPS, it can simply be restarted.

If a UPS is installed in the device, it stores the undefined state of the CPU board until it is completely discharged. This can take from a few minutes to several hours. The device must be disconnected from the power supply to discharge the UPS. After complete discharge, the device can be reconnected to the power supply and restarted.

In the above example, it may help to optimise the starting process of the power supply unit or the electronic fuse. If this does not work, a timer can be used as a further measure, which delays the start of the device by a few seconds.

5.1.2 Sluggish touch behavior

Description of error:

The touch's functionality is affected. The touch only triggers irregularly and behaves sluggishly.

Description:

This behavior can be caused by the power supply if there is no conductive connection between GND of the power supply side and FE of the device side.

Instruction Manual: Touch Industrial PC

Affected CPU boards:

- Argon: Intel® Celeron™ N3350 1.1 GHz
- Titanium: Intel® Celeron™ 3965U 2.2 GHz
- Titanium: Intel® Core™ i3-7100U 2.4 GHz
- Titanium: Intel® Core™ i5-7300U 2.6 GHz
- Titanium: Intel® Core™ i7-7600U 2.8 GHz

Solution:


A power supply unit must be used with a conductive connection between GND of the power supply side and FE of the device side. Christ provides these power supply units.

Instruction Manual: Touch Industrial PC

6 Accessories and Spare Parts

The accessories listed here have been checked by Christ and are compatible with the products.
The following accessories are available:

6.1 Power supply



Input Voltage	90 - 264 VAC
Input Current	max. 1 A
Input Frequency	47 - 63 Hz
Consumption with unloaded output	max. 0.075 W
Output Voltage	24 VDC
Output Current	max. 2.5 A
Temperature Range Operation	0 - 70°C
Humidity Operation	20 - 80% RH non condensing

Table 33: Power supply

6.2 Stand




Illustration 42: Stand large

VESA75 Stand large

Height 210 mm

Setting angle 0 - 99°

12.1" - 24"

Table 34: Stand large




Illustration 43: Stand small

VESA75 Stand small

Height 150 mm

Setting angle 0 - 81°

7" - 10.4"

Table 35: Stand small

Instruction Manual: Touch Industrial PC

7 Software

The Software chapter describes settings and functions that may be required to use the device.

The x86 architecture has a BIOS (Basic Input Output System) for the basic settings of the system. This is not present in the ARM architectures. Here, updates are performed with **CURT** (Christ Update and Recovery Tool).

7.1 BIOS Basic Settings

AMI BIOS ROM has built-in settings program that allows users to make basic settings. This information is stored in a battery supported CMOS RAM, so it remains stored even when there is no power supply.

Accessing the BIOS works by pressing the "Del" key several times while the device is booting.

The following tabs in the BIOS enable various settings.

Main	Set date
Advanced	Make advanced BIOS settings like: COM, ACPI, etc.
Chipset	Enter host bridge parameters
Security	Set administrator password
Boot	Set Boot Option
Save & Exit	Save the settings made and initiate a restart. (Also possible with the F4 key on the keyboard)

Table 36: BIOS

Pressing F3 and confirming the query "Load Optimized Defaults?" with "Yes" restores the delivery state.




Illustration 44: BIOS

Instruction Manual: Touch Industrial PC

7.1.1 Set display resolution

Set Display Channel and Resolution

Argon / Titanium

The following settings can be made in the BIOS:

1. Select "Advanced" tab
2. Select "LVDS Configuration"
3. Select "LVDS Channel Type" (Set "Dual" for Full HD displays)
4. Select "LCD Panel Type"
5. Set resolution
6. Save with keystroke "F4" (confirmation with "Yes")




Illustration 45: BIOS Display Resolution

7.1.2 COM Port configuration

COM Port configuration

Argon

In order for RS-232, RS-422 and RS-485 to be recognized on the COM port, the following settings must be made in the BIOS:

1. Select "Advanced" tab
2. Select "F81804 Super IO Configuration"
3. Select "Serial Port1 Configuration"
4. Make setting in "Device Mode" (RS-422 / RS-485 / RS-232)
5. Save with keystroke "F4" (confirmation with "Yes")

COM Port configuration

Titanium

In order for RS-232, RS-422 and RS-485 to be recognized on the COM port, the following settings must be made in the BIOS:

Instruction Manual: Touch Industrial PC

1. Select "Advanced" tab
2. Select "F81804 Super IO Configuration"
3. Select "Serial Port1 Configuration"
4. Under "F81846 SERIAL PORT1 MODE SELECT" select the mode (RS232, RS422, RS485)
5. If RS422 or RS485 mode has been selected, settings can be made for "RS422/RS485 Termination" or "RTS Auto Flow Control"
6. Save with keystroke "F4" (confirmation with "Yes")




Illustration 46: BIOS COM Port Titanium

7.1.3 Set Boot Priority

Set Boot Priority

Argon / Titanium

If you want to boot from a USB device, the following settings must be made in the BIOS:

1. Select "Boot" tab
2. Select "Boot mode select" "UEFI"
3. Open the "Boot Option #1" by pressing the "Enter" key
4. Select USB device with "Enter"
5. Save with keystroke "F4" (confirmation with "Yes")

Instruction Manual: Touch Industrial PC




Illustration 47: BIOS Boot Priority

Instruction Manual: Touch Industrial PC

7.2 BIOS Update

7.2.1 Preparation

Copy the AMI BIOS update files to a USB stick

You can obtain the required files from Christ Electronic Systems. These are the same for Argon and Titanium.

- efi
- flash.nsh
- fparts.txt
- Fpt.efi
- Titanium-200826a-S1M.bin (This .bin is only an example, the file can also be named differently)

7.2.2 Perform Update

Insert the bootable USB stick with the required files into the device.

Set the USB stick to Hard Disk Boot Priority in the BIOS. You can read about the procedure under [Boot Priority](#).

The EFI Update Script is automatically detected on the USB stick and starts the update process.

Further procedure Argon

- Confirm the question: "Enter 'q' to quit, any other key to continue:" with Enter.




Illustration 48: Argon BIOS Update

- Confirm the question "Do you want to continue? Y/<N> or q to quit:" with "y"
- The update is executed
- The message "FPT Operation Successful" indicates successful completion



Illustration 49: Argon BIOS Update successful

- Disconnect the power supply
- Restore the power supply and enter the BIOS again (do not reboot)
- Press the F3 key to confirm the question "Load Optimized Defaults" with "Yes"
- Press the F4 key to save and exit

Further procedure Titanium

Confirm the question: "Enter 'q' to quit, any other key to continue:" with Enter.

Instruction Manual: Touch Industrial PC

```
If you don't want to update, press 'q', else press any key to update!
=====
Enter 'q' to quit, any other key to continue: _
```

Illustration 50: Titanium BIOS Update

- The update is executed
- The message "FPT Operation Successful" indicates successful completion

```
FPT Operation Successful.
Done! Please turn off the system
```

Illustration 51: Titanium BIOS Update successful

- Disconnect the power supply
- Restore the power supply and enter the BIOS again (do not reboot)
- Press the F3 key to confirm the question "Load Optimized Defaults" with "Yes"
- Press the F4 key to save and exit

Instruction Manual: Touch Industrial PC

7.3 OBS Client

7.3.1 Activating the OBS Client

The OBS client is disabled by default.

To enable the OBS client, perform the following steps:

1. Launch Task Manager
2. Open "Startup" tab
3. Select "Hardware Monitor Utility for IBASE" and activate it by clicking on "Enable"




Illustration 52: Task Manager - enable OBS Client

4. Perform a restart of the device

7.3.2 Functions of the OBS Client

To start the OBS client, expand the taskbar and click on the key icon.



Illustration 53: Start OBS Client

These functions are provided by the OBS Client:

System Information

The System Information provides information about the processor and the operating system.




Illustration 54: OBS Client System Information

Instruction Manual: Touch Industrial PC

Hardware Monitor

The Hardware Monitor category indicates the approximate temperatures of the processor and peripherals.




Illustration 55: OBS Client Hardware Monitor

Settings

Various settings can be made in the Settings area.




Illustration 56: OBS Client Settings

7.4 Redo Backup and Recovery

The instructions for Christ Redo Backup and Recovery can be found in the Download section of the Christ website: [Downloads](#)


7.5 Enhanced Write Filter EWF

Instructions on how to set EWF and UWF filters can be found in the download section of the Christ website: [Downloads](#)


Instruction Manual: Touch Industrial PC

8 Maintenance

The following chapter describes maintenance measures that can be performed by a qualified end user.

NOTICE	
	Seals attacked, damage to the housing Loss of IP protection class ➤ There must be no permanent exposure to substances containing large amounts of oils or fats.

8.1 Cleaning

⚠ DANGER	
	Triggering unintended functions Loss of control of the plant / machine / device ➤ The unit may only be cleaned when it is switched off or unplugged.

To clean the device, use a soft cloth moistened with detergent solution or screen cleaner. The cleaning agent must not be applied directly to the device. Under no circumstances may aggressive solvents, chemicals or scouring agents be used.

8.2 Maintenance

It does not require any maintenance on the part of the user.

Instruction Manual: Touch Industrial PC

9 Technical Data

This chapter summarizes the technical data.

9.1 Mechanical Specifications

The weight specifications are maximum guideline values. They are given in the unit kilogram [kg].

	VESA	VESA Automation	Front Panel	Open Frame
7"	1.4	--	1.4	--
10.1"	2.3	--	2.3	1.9
10.4"	2.3	--	2.3	tbd
12.1"	2.7	--	2.7	tbd
13.3"	2.8	tbd	2.7	tbd
15"	3.7	--	3.7	tbd
15.6"	3.8	4.5	3.8	tbd
18.5"	4.9	5.8	4.7	tbd
21.5"	5.9	7.0	5.7	tbd
24"	6.5	7.6	6.3	tbd

Table 37: Weight

For IP65 rear, the above weight specification must be supplemented by the corresponding value:

VESA	0.5 kg
VESA Automation	0.6 kg

Table 38: IP65 Weight

9.2 Electrical Specifications

Supply Voltage	9,6 VDC ... 28,8 VDC
Power Consumption	see table Power Consumption
Inrush Current (load-independent)	max. 70A for 80 μ s (Used power supply: FSP060-DAAN3)
External Power Supply	SELV
Earthing	Functional Earthing (Cable cross-section has to be identical to the supply lines)
Battery Lifetime	4 years (constantly turned off)


Table 39: Electrical Specifications

Instruction Manual: Touch Industrial PC

9.3 Power Consumption

Display Size	Power Consumption
7"	up to 55 W
10.1"	up to 60 W
10.4"	up to 55 W
12.1"	up to 65 W
13.3"	up to 70 W
15"	up to 65 W
15.6"	up to 70 W
18.5"	up to 80 W
21.5"	up to 75 W
24"	up to 75 W

Table 40: Power Consumption

NOTICE	
	Specifications are maximum values Peripheral devices are considered (e.g. 1 x USB 2.0 equals 2,5 W)

9.4 Electromagnetic Compatibility

Emitted Interference	EN55032 Class A
Immunity of supply line DC	± 2 kV according to IEC 61000-4-4; EFT $\pm 0,5$ kV according to IEC 61000-4-5; Surge asymmetrical
Immunity of signal lines	± 1 kV according to IEC 61000-4-4; EFT
ESD	± 4 kV Contact discharge according to EN61000-4-2 ± 8 kV Air discharge according to EN 61000-4-2
Immunity of conducted emission	3 V 150 kHz – 80 MHz, 80% AM nach IEC 61000-4-6
Immunity of high-frequency radiation	3 V/m 80 MHz – 1 GHz, 80% AM nach IEC 61000-4-3 3 V/m 1 GHz – 6 GHz, 80% AM nach IEC 61000-4-3


Table 41: Electromagnetic Compatibility

Instruction Manual: Touch Industrial PC

9.5 Environmental Conditions

Ambient Temperature (Standard Conditions)	0 ~ 50 °C
Ambient Temperature (Different Conditions)	0 ~ 40 °C (see device-specific datasheet)
Storage Temperature	-10 ~ 70 °C
Humidity	5 ~ 80 % (non condensing)
Protection Class (Standard Conditions)	IP65 (IP20 rear)
Protection Class (Different Conditions)	IP65 (see device-specific datasheet)
Shock Resistance (Sinusoidal Vibration)	EN 60068-2-6: 5...9 Hz at individual amplitudes of 1,5 mm 9...200 Hz constant acceleration: 30 m/s ² X, Y, Z orientations with 10 cycles (approx. 10 min)
Shock Resistance (Shock)	EN 60068-2-27 70 m/s ² , 3 times in X, Y, Z - orientations
Transportation and Storage	Suitable packing increases shock resistance
max. Installation Altitude	2000 m
Cooling	Natural Air Convection

Table 42: Environmental Conditions

NOTICE	
	Insufficient air supply to the device Overheating ➤ Never cover the device completely or operate it in a small, unventilated housing

9.6 Temperature test

The values for ambient temperature and humidity were determined under worst-case conditions. The maximum workload of the system was achieved by the BurnInTest from PassMark Software Pty Ltd.

The test ran under 100 % utilisation of:

- CPU
- RAM
- 2D and 3D Graphic (x86 only)
- Brightness of the display

9.7 IP Protection Class

The protection class only can be guaranteed under the following conditions:


Instruction Manual: Touch Industrial PC

- The device is installed correctly
- All components and covers of the interfaces are assembled
- Compliance with all environmental conditions

9.8 Display Specifications

Color Depth	8 bit
Lifetime	min. 50,000 h
Viewing Angle (right/left/up/down)	min. 85°/85°/85°/85°
Backlight	LED
Touch Technology	PCAP

Table 43: Display Specifications

NOTICE	
	Pixel Errors Due to the manufacturing process, displays may contain faulty pixels (pixel errors), which do not constitute a claim or warranty.

The international standard ISO 9241-307:2009 defines, on an international level, the maximum possible pixel errors in an LC-display. This standard describes different error types, in consideration of different pixel error classes.

There are the following pixel error classes, each with three different error types:

Maximum acceptable errors per 1 Mio. pixels according to ISO 9241-307:2009				
error class	error type 1 pixel constantly illuminated	error type 2 pixel constantly dark	error type 3 subpixel constantly illuminated	error type 4 subpixel constantly dark
0	0	0	0	0
I	1	1	$n = 0 \text{ to } 2$ $2 - n$	$2 \times n + 1$
II	2	2	$n = 0 \text{ to } 5$ $5 - n$	$2 \times n$
III	5	15	max. 50	max. 50
IV	50	150	max. 150	max. 150

Why this classification of errors?

Each pixel of a display contains three subpixels which have the basic colors red, green and blue. The combination makes it possible to show a wide spectrum of colors.

Considering for example the display solution of 1280 x 800 pixels, thereof a total of 1,024,000 pixels or 3,072,000 subpixels are embedded in the display area. This means, the display holds 3,072,000 single transistors at an area of 261.1 mm by 163.2 mm.

Instruction Manual: Touch Industrial PC


These figures make it clear that it is not possible to specifically produce defect-free displays even by today's manufacturing standards.

Christ Electronic Systems GmbH therefore adapts to the corresponding requirements of most international manufacturers. The displays must always comply with error class II. If the permissible number of errors of the pixel error class II is not exceeded, there is also no complaintable "failure" of the display.

Referring to the calculation, the following errors can occur in the display:

- Max. 2 constantly illuminated and 2 constantly dark pixels
- Max. 5 constantly illuminated or 10 constantly dark subpixel

Avoid burn-in on displays

NOTICE	
	<p>Images that do not change</p> <p>"Image shadows", "ghost images" arise</p> <p>➤ Changing displayed images, screen saver, energy-saving mode</p>

With LC displays, so-called "ghost images" or "image shadows" can occur under certain circumstances. These are images that remain from the previous image and are felt to be "burnt into" the display. These do not remain forever. If "image shadows" occur, the device should be switched off for a longer period of time so that the burnt-in image disappears.

To avoid "ghost images" or "image shadows", the following behaviour is recommended:

- Do not display still images over an extended period of time
- Change standing images at short intervals
- Switch off the unit or use the energy-saving mode when you do not need it
- Use the screen saver function

Instruction Manual: Touch Industrial PC

10 Standards and Approvals

The device meets the following requirements.

10.1 CE Marking



The device has been tested in accordance with the applicable EU directives and the associated harmonized standards.

10.2 RoHS



The device complies with the requirement of the EU Directive RoHS 2011/65/EU.

10.3 Electromagnetic Compatibility

The device complies with the requirements of the EU Electromagnetic Compatibility Directive 2014/30/EU with the harmonized standards listed below:

EN 55032: 2015 Class A	Electromagnetic compatibility of multimedia equipment - Emission Requirements
EN 55035: 2017	Electromagnetic compatibility of multimedia equipment - Immunity requirements

10.4 Environmentally Appropriate Disposal

The device must not be disposed of with domestic waste.



The appliance complies with the requirement of the EU Directive WEEE 2012/19/EU, which is symbolised by the symbol with the crossed-out dustbin.

In order to enable environmentally friendly recycling, the various materials must be separated from one another.

Disposal must be carried out in accordance with the applicable legal regulations.

Component parts	Disposal
Enclosure	Metal Recycling
Electronic	Electronics Recycling
Paper / cardboard packaging	Paper / Cardboard boxes Recycling
Plastic packing materials	Plastics Recycling

Instruction Manual: Touch Industrial PC

11 Technical Support

Despite the highest quality standards and detailed function tests of all our products, daily use of our devices can always lead to damage or failure of a wearing part. The failure of a machine in production costs a lot of money. That is why the Christ company processes complaints as quickly as possible.

You can send the device to us without prior notice. All you need to do is fill out the [repair cover letter](#) and enclose it with the touch panel or IPC so that the service department can start the repair quickly. When the device arrives, it goes through a defined process that clearly documents all processes and makes the respective status traceable. As soon as your panel or IPC is registered in our system, you will receive a confirmation of receipt so that you can also get a precise overview.

Technical Support can be contacted as follows:

Service, Repair and Technical Support

Phone: +49 8331 8371-500

Fax: +49 8331 8371-497

E-Mail: service@christ-es.de

Or directly via the Homepage.

[Christ Service](#)

11.1 Device Seal

A device seal is affixed to every Christ device in order to prove whether the device has been opened by a third party. In case of a defect, please do not open the device, but contact our service department. They will discuss the further procedure with you.

Touch Industrial PC

Instruction Manual

Index of Illustration

Illustration 1: VESA Front	9
Illustration 2: VESA Rear	9
Illustration 3: VESA IP65 Front	9
Illustration 4: VESA IP65 Rear	9
Illustration 5: Dimensions VESA	10
Illustration 6: Dimensions VESA Rear	10
Illustration 7: VESA IP65 Cover	11
Illustration 8: VESA Automation Front	12
Illustration 9: VESA Automation Rear	12
Illustration 10: VESA Automation IP65 Front	13
Illustration 11: VESA Automation IP65 Rear	13
Illustration 12: Dimensions VESA Automation	13
Illustration 13: Dimensions VESA Automation Rear	14
Illustration 14: VESA Automation IP65 Cover	14
Illustration 15: Front Panel Front	20
Illustration 16: Front Panel Rear	20
Illustration 17: Dimensions Front Panel	20
Illustration 18: Dimensions Front Panel Rear	21
Illustration 19: Dimensions Front Panel Cutout	21
Illustration 20: Open Frame Front	22
Illustration 21: Open Frame Rear	22
Illustration 22: Dimensions Open Frame	23
Illustration 23: Dimensions Open Frame Rear	23
Illustration 24: Dimensions Open Frame Cutout Counterplate	24
Illustration 25: Dimensions Open Frame Cutout Front- and Spacerplate	24
Illustration 26: Installation Open Frame Cutout	25
Illustration 27: Connection of the power supply	35
Illustration 28: Mounting VESA Step 1	36
Illustration 29: Mounting VESA final situation	36
Illustration 30: Mounting VESA IP65 initial situation	37
Illustration 31: Mounting VESA IP65 Step 1	37
Illustration 32: Mounting VESA IP65 Step 2	37
Illustration 33: Mounting VESA IP65 Step 3	37
Illustration 34: Mounting VESA IP65 Step 4	38
Illustration 35: Mounting VESA IP65 final situation	38
Illustration 36: Mounting Front Panel Step 1	39
Illustration 37: Mounting Front Panel Step 2	39
Illustration 38: Mounting Front Panel Step 3	39
Illustration 39: Mounting Open Frame Step 1	40
Illustration 40: Mounting Open Frame Step 2	40

Touch Industrial PC

Instruction Manual

Illustration 41: Mounting Open Frame Step 3	40
Illustration 42: Stand large	43
Illustration 43: Stand small	43
Illustration 44: BIOS	44
Illustration 45: BIOS Display Resolution	45
Illustration 46: BIOS COM Port Titanium	46
Illustration 47: BIOS Boot Priority	47
Illustration 48: Argon BIOS Update	48
Illustration 49: Argon BIOS Update successful	48
Illustration 50: Titanium BIOS Update	49
Illustration 51: Titanium BIOS Update successful	49
Illustration 52: Task Manager - enable OBS Client	50
Illustration 53: Start OBS Client	50
Illustration 54: OBS Client System Information	50
Illustration 55: OBS Client Hardware Monitor	51
Illustration 56: OBS Client Settings	51

Touch Industrial PC

Instruction Manual

Index of Tables

Table 1: History	5
Table 2: System overview Argon	8
Table 3: System overview Titanium	8
Table 4: VESA Front and VESA Rear	9
Table 5: VESA IP65 Front and VESA IP65 Rear	9
Table 6: Dimensions VESA	11
Table 7: VESA Automation Front and VESA Automation Rear	12
Table 8: VESA Automation IP65 Front and VESA Automation IP65 Rear	13
Table 9: Dimensions VESA Automation	14
Table 10: Front Panel Front und Front Panel Rear	20
Table 11: Dimensions Front Panel	21
Table 12: Dimensions Front Panel Cutout	22
Table 13: Open Frame Front und Open Frame Rear	22
Table 14: Dimensions Open Frame	24
Table 15: Dimensions Open Frame Cutout	24
Table 16: Pinout Supply Connector screwable	26
Table 17: Pinout USB 2.0	26
Table 18: Pinout USB 3.0	27
Table 19: Pinout Ethernet	27
Table 20: Pinout WLAN	27
Table 21: Pinout Serial Connector Titanium	28
Table 22: Pinout Serial Connector Celeron N3350 Argon	29
Table 23: Pinout UPS	29
Table 24: Pinout Display Port	30
Table 25: Pinning Phoenix DMCV 1,5/13-G1F-3,5-LR P20THR	31
Table 26: Pinning Phoenix DMCV 1,5/8-G1F-3,5-LR P20THR	32
Table 27: UPS buffer duration	32
Table 28: Add On Ethernet and USB	33
Table 29: Wireless LAN	33
Table 30: Add On side USB 2.0	33
Table 31: Add On side USB 3.0	33
Table 32: Add On side Power Button	33
Table 33: Power supply	43
Table 34: Stand large	43
Table 35: Stand small	43
Table 36: BIOS	44
Table 37: Weight	53
Table 38: IP65 Weight	53
Table 39: Electrical Specifications	53
Table 40: Power Consumption	54

Touch Industrial PC

Instruction Manual

Table 41: Electromagnetic Compatibility	54
Table 42: Environmental Conditions	55
Table 43: Display Specifications	56